


This Box Contains These Parts:

OUTBACK Country Lodge™


WARNING For safety, remove all collars and leashes before allowing pet to enter any cage.




Wood Screw (12pcs)




Nuts & Bolts (8pcs)




Front Panel




Back Panel




Roof (2pcs)




Left Side Panel



Right Side Panel



Ridge Cap




Floor (2pcs)


Assembly Instructions *Screwdriver Needed for Assembly

Attach Front Panels to Side Panels Required Components

STEP 1




Nuts & Bolts (8pcs)




Front Panel


Back Panel



Left Side Panel




Right Side Panel




building
instruction

Drop in Floor. * Floors may be removed through door after roof is attached Required Components

STEP 2



Floor (2pcs)




Attach Roof Required Components


STEP 3



Wood Screw (12pcs)





Roof (2pcs)



building
instruction

Secure Ridge Cap Adjust Feet as Needed Required Components

STEP 4



building
instruction

Finished Assembly

Available Sizes/Tailles Disponibles

	Length Longueur	Width Largeur	Height Hauteur	PART NUMBER Numéro de la pièce
	28 in. (71 cm)	30 in. (76.2 cm)	30 in. (76.2 cm)	2710-1SMALL
	30 in. (76.2 cm)	35 in. (89 cm)	32 in. (81.3 cm)	2710-2MEDIUM
	32 in. (81.3 cm)	40 in. (101.6 cm)	34 in. (86.4 cm)	2710-3LARGE

* Design and dimensions may vary slightly/L'aspect et les dimensions peuvent varier un peu

